


STX/UM96009

SAA5284 User Guide (Version 1.0)



Philips Semiconductors



**PHILIPS** 

# **USER'S MANUAL**

STX/UM96009

SAA5284 User Guide (Version 1.0)

Philips Semiconductors



**PHILIPS** 

User's Manual STX/UM96009

#### **REVISION HISTORY**

Version Remarks

1.0 First Issue.




Purchase of Philips I<sup>2</sup>C components conveys a license under the Philips I<sup>2</sup>C patent to use the components in the I<sup>2</sup>C system, provided the system conforms to the I<sup>2</sup>C specifications defined by Philips.

#### © Philips Electronics NV 1996

All rights are reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner.

The information presented in this document does not form part of any quotation, is believed to be accurate and reliable, and may be changed without notice. No liability will be accepted by the publisher for any consequence of its use. Publication thereof does not convey nor imply any license under patent - or other industrial or intellectual property rights.





User's Manual STX/UM96009

## **USER'S MANUAL**

## STX/UM96009

# SAA5284 User Guide (Version 1.0)

Author(s) **N** Thorne

Philips Semiconductors Systems Laboratory Southampton, England

**Keywords: Teletext Data Broadcast** PC

Internet

Date: 18 December, 1996

3













































of

er







#### **Preface**

The SAA5284 forms a core component of data broadcasting systems that make use of the Vertical Blanking Interval (VBI).

This User's Manual describes data broadcasting in general, and the operation, programming and application of SAA5284.

The SAA5284 is a VBI and Full Field (FF) video data acquisition device tailored for application on PC add-in cards, PC mother-boards, set top boxes and as a SAA5250 replacement. SAA5284 incorporates all the data slicing, parallel interface, data filtering and control logic. It is controlled either by a parallel interface or I<sup>2</sup>C. VBI data can be output on an ITU-R656 digital video bus.

For electrical parameters, refer to the SAA5284 data sheet.













































































## SAA5284 User Guide

(Version 1.0)

Table of Contents

### User's Manual STX/UM96009

Page Number

1	HOW T	O USE THIS GUIDE TO THE SAA5284	9
2	DATA 8	BROADCASTING SYSTEMS	9
3	SAA52	84 OVERVIEW, FEATURE LIST AND BLOCK DIAGRAM	12
4	APPLIC	CATION CIRCUIT SELECTOR	16
5	REGIS'	TER CONFIGURATION SELECTOR	17
	5.1 5.1.1 5.1.2 5.2 5.3 5.4 5.4.1 5.4.2 5.4.3 5.5	NABTS Reception using Parallel Interface Register Settings Reading Data from Packet Buffer NABTS Reception using I <sup>2</sup> C Interface NABTS and Closed Caption Reception Normal Teletext Reception using Parallel Interface Register Settings Reading Data from Packet Buffer Hamming Corrected Data Format Normal Teletext Reception using I <sup>2</sup> C Interface	18 19 20 20 20 21 22 22
6		SSING REGISTERS IN PARALLEL INTERFACE MODE: DIRECT AND DED ADDRESSING EXPLAINED	23
7	HOW T	O ADDRESS REGISTERS IN I <sup>2</sup> C INTERFACE MODE	23
8	REGIST	TER AND MEMORY MAPS	24
	8.1 8.2 8.3 8.4	Register Address Map Register Bit Listing Packet Buffer and Register Memory Map Format of Data Stored in Packet Buffer	24 25 26 27
9	REGIST	TER DESCRIPTIONS	29
	9.1 9.2 9.3 9.3.1 9.4 9.5 9.6 9.7 9.8 9.9 9.10 9.11 9.12 9.13 9.14 9.15	PN - Packet Number Register AC1 - Acquisition Control 1 LCR2LCR24 - Line Control Registers Video Data Standards Supported and Corresponding LCR Setting FC - Framing Code IP, IP2 - Interrupt Position AC2 - Acquisition Control 2 DB1 to DB4 - DataBroadcast DR - Data Received LN1, LN2 - Line Number DI1, DI2 - Data Identification PAV - Packets Available THRESHOLD - Packets Required to Cause Interrupt MASK - Mask Interrupts and DMA PTT - Packets to Transfer STAT - Interrupt and DMA Status	29 29 30 30 31 32 32 33 34 34 34 35 35
10	GLOSS	ARY	35

User's Manual STX/UM96009

Table of	Contents Cont'd	Page Number
	APPENDICES	
Α	Application Circuit for ISA Card or 8051 Based System	36
В	Application Circuit for PCI using SAA7146	37
С	Application Circuit for I <sup>2</sup> C Interface	38
D	Application Circuit Digital Video Interface	39
E	Application Circuit for Motorola Interface	40
F	Operation of SEL0 and SEL1 to Select Mode of SAA5284	41
G	I <sup>2</sup> C Interface Detailed Description	42
н	Intel-Like Interface Detailed Description	43
	<ul> <li>H.1 Direct Addressing</li> <li>H.2 Extended Addressing</li> <li>H.3 Auto-Incrementing when using Extended Addressing</li> <li>H.4 Interrupt Support in Intel-Like Interface Mode</li> <li>H.5 DMA Support in Intel-Like Interface Mode</li> </ul>	45 46 46 46 47
1	Motorola-Like Interface Mode	48
J	Digital Video Interface Mode	49

# SAA5284 User Guide

User's Manual STX/UM96009

(Version 1.0)

List of	Tables	<u>Pac</u>	e Numbe
1	Pin List		14
2	Register Configuration for NABTS Reception		18
3	Register Configuration for Normal Teletext Reception		21
	Register Address Listing (Addresses in Hex)		24
4			25
5	Register Bit Listing		27
6	Storage of Data in Packet Buffer		27
7	Storage of Moji Data		27
8	Storage of WSS Data		28
9	WSS Biphase Decoding		28
10	Storage of VPS Data		30
11	Data Types		33
12	Register Bit Explanation		41
F1	Interface Mode Selection using SEL0 and SEL1 Inputs		42
G1	I <sup>2</sup> C Address Selection		43
H1	Intel Interface Pin Description		45
H2	Direct Addressing READ Map		45 45
НЗ	Direct Addressing WRITE Map		
11	Interface Signals in Motorola-Like Mode		48
J1	Digital Video Bus Interface Pin Descriptions		49

#### **List of Figures**

1	Data Broadcasting Delivery Mechanisms	10
2	Typical Data Broadcast System	11
3	SAA5284 Block Diagram	13
4	SAA5284 Pin Layout	15
5	Application Circuit Selection Flow Chart	16
6	Register Configuration Quick Selection Flow Chart	17
7	Packet Buffer and Control Register Map	26
A1	Application Circuit Diagram for ISA Card	36
B1	Application Circuit Diagram for PCI Card	37
C1	Application Circuit Diagram for I <sup>2</sup> C	38
D1	Application Circuit Diagram for Digital Video Interface	39
E1	Application Circuit Diagram for Motorola Type Interface	40
H1	Memory Addressing Diagram	44
J1	Description of Format of VBI Data Inserted onto Digital Video Bus	50

Philips	Semiconductors
---------	----------------

User's Manual STX/UM96009

# SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

### 1 HOW TO USE THIS GUIDE TO THE SAA5284

Section 2 gives an overview of data broadcasting systems, including those that use the VBI. Following this, an overview of the SAA5284 is given with a block diagram and pin lists. To facilitate choosing how to apply SAA5284, Section 4 on Page 16 gives a flow chart that will lead to the required application circuit for a particular architecture of data broadcast receiver. A similar flow chart is contained in Section 5 on Page 17 for speedy selection of the register configurations. Finally, Section 9 on Page 29 contains a complete register map and descriptions.

Use of PC driver software for SAA5284 will be described in a separate document.

#### 2 DATA BROADCASTING SYSTEMS

Data broadcasting is a term used for the point to mulitpoint ('one to many') broadcast of data. Today, radio and television broadcasting are the primary means of delivering information electronically to consumers.

The principal delivery mechanisms for current data broadcasting services include:

- FM broadcasting radio channels (FM subcarrier services).
- Television broadcast channels via the Vertical Blanking Interval (VBI), sideband or full field (FF).
- Cable television broadcast channels via the Vertical Blanking Interval (VBI), sideband or full channel.
- Satellite broadcast channels via the Vertical Blanking Interval (VBI), sideband or full channel (C-band, VSAT and Ku-band services).
- Telephone networks (fixed or mobile).
- Paging channels.

Data broadcasting can use all of a dedicated channel, a portion of an existing radio or television channel, or a portion of a digital channel.

Figure 1 on Page 10 illustrates the various mechanisms for supporting data broadcasting.




Figure 1 Data Broadcasting Delivery Mechanisms

There are a wide choice of platforms for user access systems. Some common examples are:

- Multimedia PCs.
- Dedicated TV receivers.
- Set Top Boxes.

Figure 2 on Page 11 shows a block diagram of a databroadcast system using the TV signal VBI or FF to carry data and a Multimedia PC based User Access System.




Figure 2 Typical Data Broadcast System

The PC together with the ISA add-in card provided for evaluation of the SAA5284 form a point of reference USER ACCESS SYSTEM (UAS) design, as shown in the shaded USER ACCESS SYSTEM portion of Figure 2.

The VBI data would be demodulated and stored in the SAA5284's on-board 2 kbyte RAM (known as the packet buffer). Every 40 ms<sup>1</sup> the host will read this data from the packet buffer (notified by interrupt or polling). Further processing of the packets to reconstruct the original data can then be performed in software on the host CPU.

# 3 SAA5284 OVERVIEW, FEATURE LIST AND BLOCK DIAGRAM

SAA5284 is a mixed signal full custom IC. It takes analogue baseband video (CVBS) input on one of two

1. Depending on number of VBI lines used per field.

# User's Manual STX/UM96009


register selectable inputs. Multiple standards of video data from selectable VBI lines or from the whole field are acquired and stored in the on-board 2 kbyte SRAM (or packet buffer). This data is then accessible via a multistandard parallel Interface, I<sup>2</sup>C or a digital video interface. Interrupt and DMA support are provided.

When designing the SAA5284, the architectural split of the processing of VBI data between hardware and software (running on the host CPU) was analysed at length. The result is that flexibility in processing acquired VBI data is maintained, as this is done mainly in host CPU software. Meanwhile, all data acquisition and caching functions are carried out on the IC to minimise loading on the host CPU. Data demodulation is performed in hardware by a dedicated adaptive digital filter. This maximises data demodulation performance in the presence of distortion and noise on the TV signal.

This hardware/software divide is fully exploited by a range of PC drivers and funtional software modules available for use with SAA5284. These include VxDs and DLLs to perform many functions, to be more fully described in the Software User Guide.

#### Features:

- High performance multistandard data slicer.
- Intercast <sup>TM</sup> compatible.
- Teletext (WST, Chinese teletext) (625 line).
- Teletext (US teletext, NABTS and MOJI) (525 line).
- Wide Screen Signalling (WSS), Video Programming Signal (VPS).
- Closed Caption (Europe, US).
- Data broadcast, PDC (packet 30 and 31).
- User programmable data format (programmable framing code).
- 2 kbyte data cache on-board to avoid data loss and reduce host CPU overhead.
- Filtering of packets 30 and 31 standard teletext/NABTS.
- Choice of clock frequencies, direct-in clock or crystal oscillator.
- Parallel interface, Motorola, Intel, I<sup>2</sup>C and digital video bus interface.
- I<sup>2</sup>C control bus.
- Data transport by digital video bus.
- Choice of programmable interrupt, DMA or polling driven.
- Data type selectable video line by video line, with VBI and full field mode.
- Single IC with few external components and small footprint QFP44 package.
- Optimised for EMC.



SAA5284 Block Diagram Figure 3

Table 1 Pin List

Pin No	Pin Type	Pin Name <sup>1</sup>	Description
1	Input	RESET	Reset IC
2	Input	HREF	Horizontal reference pin from a DTV front-end, active low
3	Open collector	SDA	Serial data port for I <sup>2</sup> C bus
4	· Input	SCL	Serial clock input for I <sup>2</sup> C bus
5	Output	DENB	Data enable bar (for external buffers)
6	Supply	VDDX	+5 V supply
7	1/0	OscOut	Oscillator output
8	Input	Oscin	Oscillator input
9	Supply	OscGnd	Oscillator ground
10	Input	SEL0	Parallel interface format select 0
11	Input	SEL1	Parallel interface format select 1
12	1/0	Black	Video black level storage. Connected to Vss via 100 nF capacitor
13	Input	Iref	Reference current input. Connected to Vss via 27 k resistor
14	Input	CVBS1	Analogue composite video input 1
15	Input	CVBS0	Analogue composite video input 0
16	Supply	Vdda	Analogue +5 V supply
17	Supply	Vssa	Analogue ground
18	Input	Vssd	Digital ground
19	Input	Vssd	Digital ground
20 - 27	I/O	D[70] *	Data bus[70]/video data out [70]
28	Input	A0 *	Address input [0]/video data in [7]
29	Input	A1 *	Address input [1]/video data in [6]
30	Input	A2 *	Address input [2]/video data in [5]
31	Output	INT	Interrupt request
32	Open collector	RDY *	Ready/DTACK (data acknowledge)/VBI
33	Input	WR *	Intel bus write/Mot bus R_W/video data in [4]
34	Input	RD *	Intel bus read/Mot bus LDS/video data in [3]
35 .	Input	CS0	Chip select [0]
36 .	Output	DMARQ	DMA request
37	Input	DMACK *	DMA acknowledge/video data in [2]

Table 1 Pin List (Continued)

Pin No	Pin Type	Pin Name <sup>1</sup>	Description
38	Input	VPOin0	Video data in [0]
39	Input	VPOin1	Video data in [1]
40	Supply	Vssd	Digital ground
41	Supply	Vddd	Digital +5 V supply
42	Input	LLC	Digital video clock input
43	Input	LLC2	Digital video clock qualifier input
44	Input	CS1	Chip select [1]

1. Pins with \* are dual function, see description for functions separated by '/'.




Figure 4 SAA5284 Pin Layout

# 4 APPLICATION CIRCUIT SELECTOR

There are many possible architectures of data broadcast receiver, from PC add-in cards to TVs to Set Top Boxes (STBs) to 8051 based. SAA5284 has numerous modes to support these architectures. This section aims to provide quick selection of the SAA5284 mode and corresponding application circuit for the required architecture. Note that the I<sup>2</sup>C bus bandwidth is lower than that of full VBI.




Figure 5 Application Circuit Selection Flow Chart

## 5 REGISTER CONFIGURATION SELECTOR

SAA5284 has 42 registers of 8 bits each. The flow chart in Figure 6 is designed to allow a fast introduction to configuring these registers for some of the most popular applications. A complete listing of register addresses and explanation of the function of each register bit is given in Section 8 on Page 24, which also describes the complete memory map of SAA5284 and structure of the VBI data when stored in the packet buffer.




Figure 6 Register Configuration Quick Selection Flow Chart

User's Manual STX/UM96009

### 5.1 NABTS Reception using Parallel Interface

Values to set the registers to are listed in Table 2, along with a brief explanation. Appendix H explains the different ways of accessing registers when using parallel interface mode, namely *direct addressing* and *extended addressing*.

Autoincrementing is supported in parallel access mode with all extended addresses except FFh, eg: If you wish to write to LCR2 to LCR23, write 2 to direct address 1, then the next 21 bytes written to direct address 0 will each update LCRs 2 to 23.

I<sup>2</sup>C access mode does not support autoincrementing.

#### 5.1.1 Register Settings

RESET: Note that reset only clears direct addressed registers, all others need to be programmed after a power on to a known state.

Table 2 Register Configuration for NABTS Reception

Register <sup>1</sup> Abbreviated Name	Register Full Name	Value (hex)	Comments			
PN	Packet Number	2D	Controls size of on-board packet buffer. Normally set to 45, which is the maximum number of packets that may be cached. To clear the RAM, set PN = 0, then back to 45. PN is read on a frame boundary as are most registers.			
AC1	Acquisition Control 1	80	525 line mode, Hamming correction off, see Section 5.4.3 for a description of hamming corrected data format.			
LCR2 to 6	Line Control Registers 2 to 6	FF	Do not acquire data on NTSC lines 5 to 9.			
LCR7 to 15	Line Control Registers 7 to 15	СС	NABTS data type. The framing code is set by the FC register, see below. [Assumes you want to receive data on NTSC lines 10 to 18 on both fields.]			
LCR16 to 24	Line Control Registers 16 to 24	FF	Do not acquire data on NTSC lines 19 to 27.			
FC	Framing Code	E7	Set to framing code of NABTS.			
IP1 and IP2	Interrupt Position 1 and 2	xx	Don't care unless bit 5 of MASK is cleared and interrupts are being used. Then it sets the line on which INT output goes high after THRESHOLD number of packets are in the packet buffer.			
AC2	Acquisition Control 2	00 or 02	00h if packet filtering not used, set to 02h if packet filtering required. Assumes 12 MHz clock being used.			
DB1 to DB4	Data Broadcast 1 to 4	xx	Don't care unless AC2 bit 1 is set. Then each DB register controls one 'filter channel'. If you want packet 30 from magazine 1, then set to 3Eh, ie: M2, M1, M0 = 001b = magazine 1, set R4 to R0 = 11101b = row 30			
DR	Data Received		Status register, read only.			

Table 2 Register Configuration for NABTS Reception (Continued)

Register <sup>1</sup> Abbreviated Name	Register Full Name	Value (hex)	Comments
LN1 and LN2	Line Number1 and 2		Read only.
Ignore next to	wo rows if not using	interru	ots
MASK	Interrupt MASKing		Used for enabling interrupts. For interrupt on threshold, set INTT_EN. THRESHOLD register is set to the number of packets in the packet buffer that cause an interrupt.
STAT	Interrupt STATus		The interrupt is cleared by reading the STAT register. Bit 7 of STAT is the INT on threshold flag.
PAV	Packets AVailable		Read only. The number of Packets AVailable in the packet buffer.
PTT	Packets To Transfer		Used for Direct Memory Access support, see Section 9.14 and Appendix H for complete description.

<sup>1.</sup> For register address, see Table 4 on Page 24.

#### 5.1.2 Reading Data from Packet Buffer

Section 8.4 on Page 27 gives a description of the format of data in the packet buffer.

SAA5284 contains a FIFO for reading data from the packet buffer.

To read a packet of NABTS from the packet buffer:

Synchronise to start of the current line in the packet buffer by issuing a RESET\_CURRENT command to the FIFO by doing a write to direct address 1 of FEh (or, if you want to skip a line, do a RESET\_NEXT by writing FDh to direct address 1). Write FFh to direct address 001b to allow the FIFO to be read.

Prime the FIFO (necessary after any RESET\_NEXT or RESET\_CURRENT command) by reading a byte from direct address 0 and discarding it.

Read 34 bytes from direct address 0, this is the line of NABTS data including everything after the framing code plus two bytes at the start of the packet called DI (Data Information) bytes. These tell which video line and field number the data is from, and the type of the data. Section 9.10 on Page 33 describes the DI bytes in detail.

One packet of NABTS data has been read.

To read the next line, continue to read from direct address 0 and discard the 10 bytes of junk data until the start of the next line. The 10 bytes of junk data are stored because each packet buffer is 44 bytes long (to hold a 625 line Teletext packet). To avoid reading junk data, it is possible to issue a RESET\_NEXT to start reading the next NABTS line.

### 5.2 NABTS Reception using I<sup>2</sup>C Interface

The registers are set to the same values as described in Section 5.1.1. See Table 4 for a complete register address map in I<sup>2</sup>C and parallel access modes. Section 7 on Page 23 describes in some more detail how to read from the FIFO using I<sup>2</sup>C. Note that RESET\_NEXT and RESET\_CURRENT I<sup>2</sup>C sub-addresses are different from the extended addresses used in parallel access mode.

I<sup>2</sup>C access mode does not support autoincrementing, so to update LCRs 2 to 23, a separate write to sub-address is required to point to each LCR in turn.

The I<sup>2</sup>C address may be 20h or 22h depending on the setting of SEL0 and SEL1 pins, see Appendix G.

### 5.3 NABTS and Closed Caption Reception

The registers are set to the same as Section 5.1 apart from the LCR (line control register) on which the Closed Caption signal is present. Closed Caption is normally broadcast on line 21 of the video, this corresponds to LCR18 because the **LCRs** use the **PAL** line numbering system.

Therefore LCR18 is set to 55h (for reception of Closed Captions on both fields, 05h for reception on field 1 only or 50h for reception on field 0 only).

As described in Section 8.4 on Page 27 the two Closed Caption bytes are stored in one 44 byte long row of the packet buffer. It may be desirable to use the RESET\_NEXT FIFO command to avoid the need to read out 40 bytes of junk data.

### 5.4 625 line WST Reception using Parallel Interface

The values to set the registers to are listed in Table 3, along with a brief explanation. Appendix H explains the different ways of accessing registers when using parallel interface mode, namely *direct* addressing and extended addressing.

Autoincrementing is supported in parallel access mode, eg: if you wish to write to LCR2 through to LCR23, write 2 to direct address 1, then the next 21 bytes written to direct address 0 will each update LCRs 2 to 23.

Note that I<sup>2</sup>C access mode does not support autoincrementing.

#### **Register Settings** 5.4.1

Note that reset only clears direct addressed registers, all others need to be programmed after RESET: a power on to a known state.

Register Configuration for Normal Teletext Reception

	Register <sup>1</sup> Abbreviated Name	Register Full Name	Value (hex)	Comments
0	PN	Packet Number	2D	Controls size of on-board packet buffer. Normally set to 45, which is the maximum number of packets that may be cached. To clear the SRAM, set PN= 0, then back to 45. PN is read on a frame boundary as are most registers.
1	AC1	Acquisition Control 1	00	(625 line mode).
2+	LCR2 to 6	Line Control Registers 2 to 6	FF	Do not acquire data on PAL lines 2 to 6.
	LCR7 to 22	Line Control Registers 7 to 23	00	Standard Teletext data type. [Assumes you want to receive data on lines 7 to 22 on both fields.]
	LCR23 and 24	Line Control Registers 24 & 24	FF	Do not acquire data on PAL lines 23 and 24.
20	FC	Framing Code	XX	Don't care.
21	IP1 and IP2	Interrupt Position 1 and 2	XX	Don't care unless bit 5 of MASK is cleared and interrupts are being used. Then it sets the line on which INT output goes high after THRESHOLD number of packets are in the packet buffer.
23	AC2	Acquisition Control 2	00 or 02	00h if packet filtering not used, set to 02h if packet filtering required. Assumes 12 MHz clock used.
(0-63	DB1 to DB4	Data Broadcast 1 to 4	XX	Don't care unless AC2 bit 1 is set. Then each DB register controls one 'filter channel'. If you want packet30 from mag1, then set to 3Eh, ie: M2, M1 M0 = 1 = mag1 and R4 to R0 = 30 = row 30.
28	DR	Data Ready		Status register, read only.
29 2A	LN1 and LN2	Line Number1 and 2		Read only.
	Ignore next two	rows if not using inter	rupts	
	MASK	Interrupt MASKing		Used for enabling interrupts. For interrupt on threshold, set INTT_EN. THRESHOLD register is set to the number of packets in the packet buffer that cause an interrupt.
	STAT	Interrupt STATus		The interrupt is cleared by reading the STAT register. Bit 7 of STAT is the INT on threshold flag.
	PAV	Packets AVailable		Read only. The number of Packets AVailable in the packet buffer.
	PTT	Packets To Transfer		Used for Direct Memory Access support, see Section 9.14 and Appendix H for complete description.

<sup>1.</sup> For register address, see Table 4.

User's Manual STX/UM96009

#### 5.4.2 Reading Data from Packet Buffer

Reading data from the packet buffer is performed as for NABTS, as described in Section 5.1.2.

#### 5.4.3 Hamming Corrected Data Format

For normal teletext, the Magazine and Row bytes will be hamming decoded, ie: the first byte will contain bits 0 to 7 as follows. (This is because hamming correction is compulsory for WST. To receive WST without hamming correction, set the LCRs to 88h and bit 6 of AC1 to 1.)

bit 0 = M0, bit 1 = M1, bit 2 = M2, bit 3 = R0, bit  $4 = HAM\_ERROR$ , bit 5 to 7 = don't care.

The second byte is bit 0 = R1, bit 1 = R2, bit 2 = R3, bit 3 = R4, bit  $4 = HAM\_ERROR$ , bits 5 to 7 are don't care.

Where M0 to M2 are magazine bits and R0 to R4 are row bits. HAM\_ERROR is 1 if an unrecoverable double bit error has occurred in mag/row group, single bit errors are corrected.

#### 5.5 Normal Teletext Reception using I<sup>2</sup>C Interface

The registers are set to the same values as in Section 5.4.1. See Table 4 for a complete register address map in I<sup>2</sup>C and parallel access modes. Section 7 on Page 23 describes in some more detail how to read from the FIFO using I<sup>2</sup>C. Note that RESET\_NEXT and RESET\_CURRENT I<sup>2</sup>C sub-addresses are different from the extended addresses used in parallel access mode.

1<sup>2</sup>C access mode does not support autoincrementing, so to update LCRs 2 to 23, a separate write to sub-address is required to point to each LCR in turn.

The I<sup>2</sup>C address may be 20h or 22h depending on the setting of SEL0 and SEL1 pins, see Appendix G.

User's Manual STX/UM96009

# 6 ADDRESSING REGISTERS IN PARALLEL INTERFACE MODE: DIRECT AND EXTENDED ADDRESSING EXPLAINED

There are three different methods used to access registers using the parallel interface. Figure H1 on Page 44 shows a diagram of these addressing methods.

- 1) Direct addressing uses the A0, A1, A2 pins to address 8 addresses.
  - MASK, PAV, THRESHOLD, STAT, PTT are direct addressed.
- 2) Extended addressing uses direct addresses 0 and 1 to address the rest of the registers.
  - EG: to write 44h to LCR2, write 2 to direct address 1, then write 44h to direct address 0.

Extended addresses are autoincrementing, so to write 55h to LCR3, follow on with a write of 55h to direct address 0 and so on.

3) Use of the FIFO, reading data from the packet buffer is described in detail in Section 5.1.2.

## 7 HOW TO ADDRESS REGISTERS IN I<sup>2</sup>C INTERFACE MODE

The I<sup>2</sup>C interface is a slave type with a programmable address of 20h or 22h as described in Appendix G. Registers are accessed using sub addresses, with no autoincrementing.

1<sup>2</sup>C sub addresses for the registers are listed in Table 4.

The main areas of difference between I<sup>2</sup>C addresses and parallel addresses are for the direct addressed registers (eg: PAV) and the RESET\_NEXT and RESET\_CURRENT values as shown in Table 4.

To read data out from the packet buffer FIFO, read from sub address 7Fh. Multiple FIFO reads may be made.

To do a RESET\_CURRENT, write to sub address 79h, prime the FIFO, then continue as normal to read the FIFO data.

For RESET\_NEXT, do the same as above but write 78h instead of 79h, remembering to prime the FIFO as described in Section 5.1.2.

#### 8 REGISTER AND MEMORY MAPS

#### 8.1 Register Address Map

Table 4 Register Address Listing (Addresses in Hex)

Extended Address	Direct Address	l <sup>2</sup> C Sub-Address	Read/Write	Register/Function Accessed
00	•	00	W/R	PN
01	-	01	W/R	AC1
02 to 18	- 1	02 to 18	W/R	LCR2 to LCR24
19 to 1F		19 to 1F	W/R	reserved
20	-	20	W/R	FC
21	-	21	W/R	IP1
22	-	22	W/R	IP2
23	-	23	W/R	AC2
-	2	72	W/R	MASK
	3	73	R	PAV
-	4	74	W/R	THRESHOLD
-	5	75	R	STAT
-	6	76	W/R	PTT
28	-	28	R	DR
29	•	29	R	LN1
2A	•	2A	R	LN2
60	-	60	W/R	DB1
61	•	61	W/R	DB2
62	-	62	W/R	DB3
63		63	W/R	DB4
•	1	-	W/R	Extended Address
•	01	7F	R	Packet buffer FIFO
- 6	0		R/W	Extended Addressed Data
FD		78	W	Reset Next
FE		79	W	Reset Current

1. When Extended Address set to FF.

## SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

## 8.2 Register Bit Listing

## Table 5 Register Bit Listing

			Table 5					
Register	d7	d6	d5	d4	d3	d2	d1	d0
PN	PN7	PN6	PN5	PN4	PN3	PN2	PN1	PN0
AC1	525/625	HAM	FCE	HUNT	(set to 0)	-	•	•
	DT3 f 1	DT2f1	DT1 f 1	DT0 f 1	DT3f2	DT2f2	DT1f2	DT0f2
LCR2 to LCR24	01311	0,2					504	FC0
FC	FC7	FC6	FC5	FC4	FC3	FC2	FC1	
IP1	-	V8	V7	V6	V5	V4	V3	V2
IP2	V1	VO	-	-	-		•	
AC2	-	-	FECLK1	FECLK0	padding	CVBS	DBonly	-
DB1	M2	M1	МО	R4	R3	R2	R1	R0
DB2	M2	M1	МО	R4	R3	R2	R1	R0
DB3	M2	M1	МО	R4	R3	R2	R1	R0
 DB4	M2	M1	MO	R4	R3	R2	R1	R0
DR	FC8V	FC7V	VPSV	PPV	CCV		VSQ	525R
LN1	-	-	F1/F2	LN8	LN7	LN6	LN5	LN4
LN2	LN3	LN2	LN1	LNO	DT3	DT2	DT1	DT0
MASK				INT_CLEAR	DMA_EN	DMA_DEMAND	DMA_CLEAR	-
	PAV7	PAV6	PAV5	PAV4	PAV3	PAV2	PAV1	PAV0
PAV		T6	T5	T4	T3	T2	T1	TO
THRESHOLD	-			-	-		-	
STAT	INTT	INTDD	DMA_ST AT					
PTT	PTT7	PTT6	PTT5	PTT4	PTT3	PTT2	PTT1	PTT0
PTT	PTT7	PTT6	PTT5	PTT4	PTT3	PIIZ	FIII	1 1 1 0

# 8.3 Packet Buffer and Register Memory Map




Figure 7 Packet Buffer and Control Register Map

The packet structure of the memory (ie: the format of each 44 byte segment) is described in Table 6.

User's Manual STX/UM96009

### 8.4 Format of Data Stored in Packet Buffer

Table 6 Storage of Data in Packet Buffer

		Byte Number in Packet Buffer													
Data Type	0	1	2 3	4	15	16	2	7	28	35	36	37	43		
Euro WST	DI1	DI2	MRAG <sup>1</sup> (2)			Т	eletext c	lat	a (4	0)					
US WST, NABTS	DI1	DI2	MRAG <sup>1</sup> (2)		Teletext data (32)							ndefine	ed (8)		
Moji	DI1	DI2	SI/PC <sup>2</sup> (2)		Te	eletext [	Data (33	)				Undef	ined (7)		
wss	DI1	DI2	WSS	Data <sup>3</sup> (14	<b>l</b> )			U	nde	fined	(28)				
VPS	DI1	DI2		VPS Data <sup>4</sup> (26)						Undefined (16)					
Closed Captions	DI1	DI2	CC data (2)	(2) Undefined (40)											

- 1. Magazine and Row Address Group, as per WST Specification. If HAM bit = 0 (in AC1) (or data type is WST, see Table 11), packet buffer bytes 2 and 3 contain hamming corrected data in the lower hibble only.
- 2. SI, PC and Moji data are stored as in Table 7.
- 3. Wide Screen Signalling data stored as in Table 8.
- 4. VPS data stored as in Table 10.

Table 7 Storage of Moji Data

Byte in Packet	FC		- 3	SI		F	C		Data	ì			 	Data	
Bit Number in Packet	0 7		0		7	0	5	0	7	0		7	 0	70 1	
Bit Number in RAM		0 1	2	7	01	2	7	0	. 7	0		7	 0	70	2
Byte No. in RAM	_		2			3			4		5		 35		36

Table 8 Storage of WSS Data

WSS Bit Number	Bit 0	Bit 1	Bit 2	Bit 3	<b></b>	Bit 11	Bit 12	Bit 13
Bit Number in RAM	7 0	7 0	7 0	7 0		7 0	7 0	7 0
Data in RAM	xxdddddd	xxdddddd	xxdddddd	xxdddddd		xxdddddd	xxdddddd	xxdddddd
Byte No. in RAM	2	3	4	5		13	14	15

In Table 8, xx is undefined. Each dddddd are a group of 6 bits representing a single symbol (a WSS bit) bi-phase coded and then oversampled at 3 times the baud rate. To decode the individual bits, it is usual to take a majority decision on each group of 3 bits (majority of 0s or 1s), then compare the first and second three-bit groups to do bi-phase decoding. This is illustrated in the following example:

Table 9 WSS Biphase Decoding

Stored bits b5b0	First Bit	Second Bit	Biphase Decoded	Biphase Error
111 000	1	0	1	No
000 111	0	1	0	No
101 010	1	0	1	No
101 011	1	1	_	Yes
000 011	0	1	0	No
010 000	0	0	_	Yes

Table 10 Storage of VPS Data

<b>VPS Word and</b>	Word 3 3 2 1 0 7 6 5 4						Word 4									
Bit Number	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4
Data in RAM	dd	cc	bb	aa	dd	ccl	ob	aa	dd	СС	bb	aa	dd	ccl	bba	aa
Bit Number in RAM	7			0	7			0	7			0	7			0
Byte No. in RAM		2	2			3	3			4	1			5	5	

-	Vor			Word 15							
7	6	5	4	3	2	1	0	7	6	5	4
do	cc	bb	aa	dd	СС	bb	aa	dd	cci	bb	aa
7			0	7			0	7			0
	2	5			2	6			2	7	

Each pair of bits dd, cc, bb or aa is a single symbol, biphase coded. 01 represents a 1 symbol, 10 represents a 0 symbol. 00 and 11 are biphase errors. The data can be decoded in minimum processor time by using a look-up table (256 bytes) using the received data as index, which gives the correct decoded biphase data in the ls 4 bits of each byte and 4 corresponding error flags in the ms bits; eg: a stored byte with hex value 0 x 1B (binary 00.01.10.11) would be decoded as 1001.0100 <where 1001.0100 == error\_flags.decoded\_bits> (ie: the middle two pairs 01 and 10 decode correctly to 1 and 0, but the outer two pairs 00 and 11 are errors).

## SAA5284 User Guide

(Version 1.0)

User's Manual STX/UM96009

### 9 REGISTER DESCRIPTIONS

Note that all unused register bits must be set to 0.

#### 9.1 PN - Packet Number Register

(Read/Write)

PN7	PN6	PN5	PN4	PN3	PN2	PN1	PN0	
d7	d6	d5	d4	d3	d2	d1	d0	7

See Table 4 for address. PN defines the size of the packet buffer (in multiples of 44 byte packets). It may be written to at any time by the processor. It is acted upon on a frame boundary. Note that the minimum number is 1, in which case the start of packet write address pointer will be set to the base address = 0 + 2C (maximum 45d or 45 packets). A 0 written to **PN** effectively resets the packet buffer on the next frame boundary.

Note that it is advised to only set PN to 45d or 0. Setting PN to other values can cause PAV to increment beyond PN under certain conditions.

#### 9.2 AC1 - Acquisition Control 1

(Read/Write)

d7	d6	d5	d4	d3	d2	d1	d0
525/625	HAM	FCE	HUNT	-	-	_	•

See Table 4 for address. The general control signals are written into this register at any time by the processor. The contents are read by the front-end at the start of each new frame and should be reset by software to all 0 on power on reset.

**HUNT** - stops amplitude searching if = 1.

FCE - select allowable errors in framing code: = 0: one error allowed, =1: no errors allowed.

- disables (8, 4) hamming correction of WST mag/row group if = 1.

525/625 - 525 line transmission expected if = 1.

#### 9.3 <u>LCR2..LCR24 - Line Control Registers</u>

(Read/Write)

d7	d6	d5	d4	d3	d2	d1	d0
DT3 f 1	DT2 f 1	DT1 f 1	DT0 f 1	DT3 f 2	DT2 f 2	DT1 f 2	DT0 f 2

See Table 4 for address. These registers tell the front-end what data type to receive on video lines: 2, 3, 4,... 23, (24 and after), on each field. Note that the address of the line control register in RAM is the line number. The relevant register will be read at the beginning of each line. On power on reset, the data type should be set by software to acquire nothing (DT = 1111). Registers **LCR2** to **LCR23** apply to lines 2 to 23 respectively.

User's Manual STX/UM96009

Register LCR24 applies to all lines from line 24 to the end of the field. PAL line numbering is used, ie: line 1 is the first line containing broad pulses at the start of field 1 (corresponding to NTSC Line 4). LCRn controls acquisition on line n+3 for NTSC line numbering.

DT3 f 1 - DT0 f 1: Data type, to be received on line n, first field.

DT3 f 2 - DT0 f 2: Data type to be received on line n, second field.

For Data Types, see Table 11.

#### 9.3.1 Video Data Standards Supported and Corresponding LCR Setting

Table 11 Data Types

DT	Data Type	Data Rate (Mb/s)	Framing Code	FC Window	Ham Correct
0000	Teletext EuroWST, CCST	6.9375	27h	WST625	Always
0001	European Closed Caption	0.500	001b	CC625	
0010	VPS	5.00	9951h	VPS	
0011	Wide Screen Signalling bits (WSS)	5.00	1E3C1Fh	WSS	
0100	US Teletext (WST)	5.7272	27h	WST525	Always
0101	US Closed Caption (Line 21)	0.503	001b	CC525	
0110	Reserved	-	-	-	-
0111	Reserved	<u>-</u>	-	-	-
1000	Teletext	6.9375	prog	gen_text	Optional
1001	Reserved	-	-	-	
1010	Reserved	-		-	-
1011	Reserved			-	-
1100	US NABTS	5.7272	prog	NABTS	Optional
1101	Moji (Japanese)	5.7272	prog (A7h)	Moji	
1110	Japanese Format Switch (L20/22)	5.00	prog .	open	
1111	Do not acquire	-	•	•	

#### 9.4 FC - Framing Code

(Read/Write)

d7	d6	d5	d4	d3	d2	d1	dO
FC7	FC6	FC5	FC4	FC3	FC2	FC1	FC0

See Table 4 for address. This register gives the framing code for the checker in the front end block. It is used if the msb of the data type DT3 is 1. It will be read at the beginning of the line after the LCR.

# SAA5284 User Guide

(Version 1.0)

User's Manual STX/UM96009

#### 9.5 IP, IP2 - Interrupt Position

(Read/Write)

	d7	d6	d5	d4	d3	d2	d1	d0
IP1	-	V8	V7	V6	V5	V4	V3	V2
IP2	V1	VO		-		-	•	-

See Table 4 for address. These two registers give the line number in the field of the INT signal. They are read on each frame boundary. See **MASK** register **INT\_IMM** bit for turning on and off the coordination of interrupt with line number.

V8 - V0: Vertical Position of INT, Line Number (1 - 312). PAL line numbering is used.

#### 9.6 AC2 - Acquisition Control 2

(Read/Write)

d7	; d6	d5	d4	d3	d2	d1	d0
-	-	FECLK1	FECLK0	padding	CVBS	DBonly	-

See Table 4 for address. This register controls the clock select inputs of the front end. It is read by the hardware every frame.

padding: If set to 1, padding pixels of value 42h are output until the next rising edge of the HREF input pulse, else padding pixels (value = 42h) are output onto the digital video bus until the next analogue video H-sync falling edge.

CVBS: If set to 1, CVBS1 input selected else CVBS0 input selected.

**DBonly**: If set to 1, only certain packets are stored, as set by registers DB1 to DB4 else all packets are stored.

**FECLK1** and **FECLK0** are used to tell the adaptive digital filter that performs the data demodulation what crystal (clock) frequency is in use.

FP	FECLK1	FECLK0
12 MHz	0	0
13.5 MHz	0	1
15 MHz	1	0
16 MHz	1 .	1

User's Manual STX/UM96009

#### 9.7 DB1 to DB4 - DataBroadcast

(Read/Write)

	d7	d6	d5	d4	d3	d2	d1	d0
DB4 to DB1	M2	M1	МО	R4	R3	R2	R1	R0

See Table 4 for address. **DB** (**D**ata**B**roadcast) registers allow control of selective acquisition of packets. For example in normal Teletext (WST) 16 channels are used comprising packets 30 and 31 of magazines 1 to 8.

M2 to 0

Magazine to acquire.

R4 to R0

Row (packet) to acquire.

Note, DBonly bit in AC2 turns packet filtering on and off (it stands for DataBroadcast only).

#### 9.8 DR - Data Received

(Read)

d7	d6	d5	d4	d3	d2	d1	d0
FC8V	FC7V	VPSV	PPV	CCV	-	VSQ	525R

See Table 4 for address. This register gives a general description of data and signal conditions within the last frame. Signals from the front-end set the relevant bits in the holding latch during the frame. On the frame boundary the contents are transferred to the data received latch and the holding latch is reset to 0. The Data Received latch may read by the processor at any time.

The bits of DR are defined as follows:

Bit	Significance if 1
525R	525-line transmission detected.
VSQ	Acquisition PLL in lock — Video Signal Quality good.
CCV	Closed Caption data received within last frame.
PPV	PALplus signalling data received within last frame.
VPSV	Video Programming Signal (VPS) data received within last frame.
FC7V	Teletext data received with 1 error in framing code within last frame.
FC8V	Teletext data received with no errors in framing code within last frame.

User's Manual STX/UM96009

#### 9.9 LN1, LN2 - Line Number

(Read)

	d7	d6	d5	d4	d3	d2	d1	dO
LN1	-	-	F1/F2	LN8	LN7	LN6	LN5	LN4
LN2	LN3	LN2	LN1	LNO	DT3	DT2	DT1	DT0

See Table 4 for address. These two registers contain the current line number and field. This data is written at the beginning of the new line, when the line number has settled.

F1/F2, LN8..LN0 and DT3..DT0 are as defined for DI1 and DI2 below.

#### 9.10 DI<sub>1</sub>, DI<sub>2</sub> - Data Identification

(Read)

DI1

DI<sub>2</sub>

d7	d6	d5	d4	d3	d2	d1	d0
Writing	-	F1/F2	LN8	LN7	LN6	LN5	LN4
LN3	LN2	LN1	LN0	DT3	DT2	DT1	DT0

These are the first two bytes in a packet of data read from the packet buffer FIFO (Correspond to RAM Addr: DI1 = 02Ch + n x 2Ch, and DI2 = DI1 + 1).

Table 12 Register Bit Explanation

Bits	Meaning
DT3DT0	Type of data received (see Table 11)
LN8LN0	Line number in current field (1313)
F1/F2	Set to "1" if field 2 of frame
Writing	Buffer in use: see note below

#### Writing Bit:

The **Writing** bit is set at the beginning of the line, in the same write operation as the rest of the bits of **DI1**. The **Writing** bit is reset at the beginning of the next line and written (before new values are read out of the RAM) and the register contents are written to the old start of packet address in RAM. It is commonly used by software designers to detect when the packet buffer is empty.

Wast till bit is cheaved & to ensure data is ok.

Philips Semiconductors

# SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

#### 9.11 PAV - Packets Available

(Read)

	d7	d6	d5	d4	d3	d2	d1	do ·	
PAV	PAV7	PAV6	PAV5	PAV4	PAV3	PAV2	PAV1	PAV0	

See Table 4 for address. This register contains the number of packets of data available in the packet buffer FIFO. It is useful for reading before initiating a DMA transfer of packet data, or when polling the device for new data.

PAV increments as new packets are received until it reaches PN. If PN is set to a value between 0 and 45d, that is below the current value of PAV, PAV will increment beyond PN until it wraps round. Use of this functionality is not recomended.

### 9.12 THRESHOLD - Packets Required to Cause Interrupt

(Read/Write)

	d7	d6	d5	d4	d3	d2	d1	dO
THRESHOLD	T7	Т6	T5	T4	ТЗ	T2	T1	ТО

See Table 4 for address. This register contains the number of packets that must be present in thepacket buffer to cause an INTT (INTerrupt on Threshold exceeded) interrupt.

## 9.13 MASK - Mask Interrupts and DMA

(Read/Write)

	d7	d6	d5	d4	d3	d2	d1	d0	
MASK	INTT_EN	INTDD_EN	INTT_IMM	INT_CLEAR	DMA_EN	DMA_DEMAND	DMA_CLEAR		

See Table 3 for address. This register contains DMA and Interrupt control and status information.

INTT\_EN Enable interrupt when number of packets in packet buffer exceeds value set in THRESHOLD register.

INTDD\_EN Enable interrupt on end of DMA read.

INTT\_IMM When 1, allows INTT interrupts to occur on any line. When 0, interrupts occur only on the line specified in **IP1** and **IP2**.

INT\_CLEAR

When 1, INTT\_EN or INTDD\_EN self clear when an INTT or INTDD is generated respectively (ie: on the rising edge of the interrupt).

DMA\_EN Enable SAA5284 to initiate DMA. When set, reading from the packet buffer FIFO may only take place in DMA cycles.

DMA\_DEMAND When 1, demand mode else burst mode.

DMA\_CLEAR When 1, DMA\_EN self clears when a DMA transfer is completed.

# SAA5284 User Guide

(Version 1.0)

User's Manual STX/UM96009

#### 9.14 PTT - Packets to Transfer

(Read/Write)

	d7	d6	d5	d4	d3	d2	d1	d0	_
PTT	PTT7	PTT6	PTT5	PTT4	PTT3	PTT2	PTT1	PTT0	

See Table 4 for address. This register contains the number of packets to be transferred by DMA per burst, when in DMA burst mode.

## 9.15 STAT - Interrupt and DMA Status

(Read)

	d7	d6	d5	d4	d3	d2	d1	
STAT	INTT	INTDD	DMA_STAT	=	-	-	-	-

See Table 4 for address. This register contains DMA and Interrupt control and status information.

INTT

Status bit to indicate that the interrupt was generated by the THRESHOLD being exceeded. Clears when STAT register is read.

INTDD

Status bit to indicate that the interrupt was generated by completion of a DMA transfer. Clears when STAT register is read.

DMA\_STAT

DMA status bit. It is 1 if DMA is in progress.

10 GLOSSARY

CC Closed Captioning

VBI Vertical Blanking Interval

WST World System Teletext

FF Full Field

STB Set Top Box

PAL Phase Alternating Line

PDC Program Delivery Control

WWW World Wide Web

HTML Hyper Text Markup Language

# SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

or dealearanger

UAS User Access System

Mag Magazine

#### APPENDIX A

# Application Circuit for ISA Card or 8051 Based System

Figure A1 shows an application circuit for a typical PC ISA add-in card type of application. Note that when using an 8051, with multiplexed address/data bus, the address is not latched in until up to a clock cycle after the transition of the RD or WR. Hence it may be necessary to control SAA5284 by port pins with appropriate modification to the 8051 based SAA5284 driver software.




Figure A1 Application Circuit Diagram for ISA Card

Equation listing for address decode for CS0 into SAA5284:

B1 = / ((/I0 \* I7 \* I6 \* /I5 \* /I4 \* I3 \* /I2 \* /I1) + /B0);

#### APPENDIX B

#### **Application Circuit for PCI using SAA7146**

This PCI application is based around the Philips SAA7146 video to PCI bridge IC. The SAA7146 has a "Data Expansion Bus Interface" (DEBI) which is an Intel/Motorola style 16-bit parallel interface. This is used to facilitate communication to SAA5284.




Figure B1 Application Circuit Diagram for PCI Card

SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

# APPENDIX C Application Circuit for I<sup>2</sup>C Interface

Note that I<sup>2</sup>C address is selectable, it is 22h with SEL0 and SEL1 connected to 0 V. It is 20h with SEL0 connected to +5 V and SEL1 connected to 0 V, see Table G1.




Figure C1 Application Circuit Diagram for I<sup>2</sup>C

#### APPENDIX D

# **Application Circuit for Digital Video Interface**

Digital Video Mode is described in detail in Appendix J. Basically, in PCI (or other) applications where the only interface into the host system is a digital video interface, the digital video may be routed through SAA5284. SAA5284 will then pass picture information through untouched, but will demodulate video data (on VBI or full field) and place this into the pixel stream instead of the VBI pixels (that are not displayed anyway). Software would then read the demodulated data from the pixel stream.




Figure D1 Application Circuit Diagram for Digital Video Interface

APPENDIX E

Application Circuit for Motorola Interface




Figure E1 Application Circuit Diagram for Motorola Type Interface

User's Manual STX/UM96009

### APPENDIX F

# Operation of SEL0 and SEL1 to Select Mode of SAA5284

Pins SEL0 and SEL1 are used to select the interface mode as shown in Table F1:

Table F1 Interface Mode Selection using SEL0 and SEL1 Inputs

SEL1	SEL0	Mode	I <sup>2</sup> C Address
0	0	Intel type interface	0010-001X <sup>1</sup>
0	1	Y bus (digital video bus) interface (note different I <sup>2</sup> C address)	0010-000X
1	0	Motorola type interface	0010-001X
1	1	Y bus (digital video bus) interface	0010-001X

<sup>1.</sup> X is read/write bit.

SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

#### APPENDIX G

# <u>I<sup>2</sup>C Interface Detailed Description</u>

400 kHz slave operation. 7-bit sub-address (msb is ignored), giving 7Fh read and 7Fh write addresses. Table 3 in the register map section lists the registers and their corresponding I<sup>2</sup>C addresses.

The I<sup>2</sup>C address is selectable using the SEL0 and SEL1 input pins, see Table G1:

Table G1 I<sup>2</sup>C Address Selection

SEL1	SEL0	I <sup>2</sup> C Address
0	0	0010-001X <sup>1</sup>
0	1	0010-000X
1	0	0010-001X
1	1	0010-001X

1. X is read/write bit.

decedent and the contract of t

### APPENDIX H

# Intel-Like Interface Detailed Description

Table H1 lists the pins used in Intel interface mode:

Table H1 Intel Interface Pin Description

Pin Number	Signal Name	Туре	Description
20 - 27	D[70]	1/0	Data bus.
28 - 30	A[02]	Ī	3 address bits.
35	CS0	1	Chip select, active low.
44	CS1	1 .	Chip select, active low.
34	RD	1	Read, active low.
33	WR	1	Write, active low.
31	INT	0	Maskable interrupt, active high.
36	DMARQ	0	(programmable) DMA request, active high.
37	DMACK	1	DMA acknowledge input, active low.
32	RDY	Open collector	Wait to CPU, active high.
3	SDA	Open collector	I <sup>2</sup> C data <sup>1</sup> .
4	SCL	I	I <sup>2</sup> C clock.

<sup>1.</sup> I<sup>2</sup>C may be used when parallel accesses inactive.

When using Intel-like interface (and Motorola-like), two methods of addressing are used together. These are extended addressing and direct addressing. These two addressing methods are described below and in Figure H1 on Page 44.




Figure H1 Memory Addressing Diagram

### H.1 <u>Direct Addressing</u>

Registers may be accessed using direct addressing. The A0, A1, A2 pins are used to address the 8 bytes of direct addressing I/O space. Direct addresses are listed in Tables H2 and H3 and illustrated in Figure H1.

Please note that to read data from packet buffer RAM, a special extended address is written to direct address 01h (see Table H3). This allows subsequent single cycle reads of packet buffer RAM (containing VBI data) from direct address 00h. Reading from the FIFO is described in detail in Section 5.1.2.

Table H2 Direct Addressing READ Map

A(20)	Description
000	8 bits of extended addressed data to be read.
001	Address of next byte to read or write when using extended addressing of registers. Can only access data in packet buffer RAM via FIFO. (Access to FIFO (and access mode) set by writing special address to this byte - see Table H3.)
010	MASK register.
011	PAV register.
100	THRESHOLD register.
101	STAT register.
110	PTT register.
111	Reserved.

Table H3 Direct Addressing WRITE Map

A[20]	Description
000	8 bits of extended addressed data to be written.
001	Address of next byte to read or write when using extended addressing of registers. Cannot write to packet buffer RAM. Special address causes data read out to come from packet buffer FIFO, provided DMA is disabled. Special addresses are:  0FFh - read data from FIFO when reading direct address 0.  0FEh - move FIFO read pointer to start of current line.  0FDh - move FIFO read pointer to start of next line.
010	MASK register.
011	PAV register.
100	THRESHOLD register.
101	STAT register.
110	PTT register.
111	Reserved.

# SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

#### H.2 Extended Addressing

Extended addressing allows random access to all 2Ch registers using only 3 address signals and the 8 data signals. A map of these registers is shown in Table 4. Accesses of this type require two cycles, as described below.

Cycle1: (Write)

Write to direct address 001b (A2..A0) the extended address you wish to write to, or read from in the next cycle, eg: if you want to modify LCR2 to 34h, write 2 to point to extended address 2.

Cycle 2: (Read or write)

Read from or write to direct address 000b the value of the data you addressed in the previous cycle. In this example, LCR2 is to be set to 34h. Therefore 34h is written to direct address 000b.

In the next cycle, we have a choice. If we want to read or write to LCR3, we read or write the new value of LCR3 from or to direct address 000b. The auto-incrementing function of the extended address pointer ensures that the next extended address up from LCR2 is read or modified ie: extended address 3.

Alternatively, we may wish to modify another extended address, eg: extended address 7 (LCR7). To do this, we have to start another two cycle access as already described, but with 7 written to direct address 001.

### H.3 <u>Auto-Incrementing when using Extended Addressing</u>

When reading from/writing to the register map via extended addressing, the address is auto-incremented where appropriate, eg: if LCRs are to be updated, set extended addressing register to 2, then write 21 bytes to direct address 000b to update all LCRs in one burst write.

The read pointer of the FIFO increments as bytes are read out.

#### H.4 Interrupt Support in Intel-Like Interface Mode

Two maskable interrupts are available. INTT and INTDD. INTT (INTerrupt on Threshold) is caused when the number of VBI data packets available in the packet buffer RAM reaches the number programmed into the THRESHOLD register. INTDD (INTerrupt on DMA Done) is caused by DMA transfer ending.

INTT and INTDD interrupts are enabled by the INTT\_EN and INTDD\_EN bits respectively in the MASK register. INTDD interrupts always occur immediately at the end of a DMA transfer. INTT interrupts can be programmed to occur immediately after THRESHOLD has been reached or on a certain video line number, by setting the INTT\_IMM bit in MASK and the IP1 and IP2 registers.

When an interrupt ocurs, the corresponding flag (INTT or INTDD) in STAT is set and the INT signal becomes active. If the INT\_CLEAR bit is set then the appropriate enable bit (INTT\_EN or INTDD\_EN) in MASK is cleared. When STAT is read the two interrupt flags are cleared and the INT output is deactivated. See Section 9.13 on Page 34 for more information on interrupt support.

# SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

and a contract a contract

### H.5 DMA Support in Intel-Like Interface Mode

DMA is enabled or disabled using the DMA\_EN bit in the MASK register.

When demand mode DMA is enabled by setting DMA\_DEMAND in MASK, a DMA transfer is requested by asserting DMARQ when PAV reaches the value stored in THRESHOLD. The transfer will continue until PAV reaches 0. Therefore in this mode an arbitary number of packets will be transferred.

When burst mode DMA is enabled by clearing DMA\_DEMAND in MASK, a DMA transfer is requested immediately and the number of packets stored in PTT will be transferred.

In either DMA transfer mode, the DMA\_EN bit can be automatically cleared at the end of the transfer by setting the DMA\_CLEAR bit in MASK.

When DMA is enabled, access to the packet buffer FIFO (see Tables H2 and H3) using direct addressing should not be attempted. Therefore it is necessary that **DMA\_STAT** should be checked if DMA is enabled simultaneously with reads from the FIFO by direct addressing. (The practice of mixing direct address reads of the FIFO with DMA reads is not recommended.)

## APPENDIX I

### Motorola-Like Interface Mode

Table I1 lists the pins used in Motorola-like interface mode.:

Table I1 Interface Signals in Motorola-Like Mode

Pin Number	Signal Name	Туре	Description
20 - 27	D[70]	1/0	Data bus.
28 - 30	A[02]	1	3 address bits.
35	CS0	1	Chip select, active low.
44	CS1	1	Chip select, active low.
34	LDS	1	Data strobe.
33	R/W	ı	Read/write.
31	INT	0	Programmable interrupt, active low.
36	DMARQ	0	(Programmable) DMA request, active low.
37	DMACK	1	DMA acknowledge input, active low.
32	DTACK	Open collector	Data acknowledge, active low.

Direct addressing, extended addressing, DMA support, interrupt support and autoincrementing are the same as in Intel-type mode.

#### APPENDIX J

#### **Digital Video Interface Mode**

Table J1 describes the pins used in this mode. Appendix D contains a circuit diagram for application in this mode:

Table J1 Digital Video Bus Interface Pin Descriptions

Pin No	Signal Name	Туре	Description
2	HREF	1	Horizontal synchronisation pulse in (active high).
3	SDA	Open collector	I <sup>2</sup> C data in (for control of SAA5284 in digital video interface mode).
4	SCL	1	I <sup>2</sup> C clock.
27 - 20	VPOout(70)	0	Pixel data/VBI data out.
28	VPOin7	I	Pixel data in 7.
29	VPOin6	1	Pixel data in 6.
30	VPOin5	ı	Pixel data in 5.
32	VBI	0	High when VBI data acquisition enabled on present line. Duration affected by <b>padding</b> bit in <b>AC2</b> (active high).
33	VPOin4	1	Pixel data in 4.
34	VPOin3	I	Pixel data in 3.
35	CS0	I	Used for direction control of dig vid bus. Tristates VPOout(70) if high.
37	VPOin2	1	Pixel data in 2.
38	VPOin0	1	Pixel data in 0.
39	VPOin1	1	Pixel data in1.
42	LLC	ı	Pixel clock signal.
43	LLC2	ı	Pixel clock qualifier signal, active high.
44	CS1	I	Used for direction control of dig vid bus. Tristates VPOout(70) if high.

It is important to note that the register map may only be accessed by I<sup>2</sup>C in digital video bus mode.

When passed through SAA5284, digital video data is always delayed by one LLC cycle. This is due to resynchronisation. When using with an SAA7111 with 16-bit YUV, it may be necessary to delay the chroma by a number of samples to regain Y vs UV synchronisation.

Note that the acquired VBI data is split into two nibbles (see Figure J1), which are placed onto digital video data signals VPO0 to VPO7. VPO0 is a data available flag. It is 1 when a data nibble is present, 0 when a padding pixel is present. Software must reconstruct the original data byte from the two pixels. This is to avoid a 00h value on the ITU656 bus which the specification does not allow. VPO6 is even parity for VPO[5..0] (labelled 'P'), VPO7 is not P. Padding pixels will either be added until next HREF.

Philips Semiconductors

SAA5284 User Guide (Version 1.0)

User's Manual STX/UM96009

or until next H sync detected by the on-board sync separator, depending on setting of **padding** bit in **AC2**.




Figure J1 Description of Format of VBI Data Inserted onto Digital Video Bus

A 4 pixel key is used to signal that this line contains VBI data. The key is A5h 41h C5h 41h, in consecutive pixels. The key and (nibble-ised) DI information are placed onto the pixel bus just before the earliest possible first data byte, which is 12  $\mu$ s after H sync falling edge. This means that once an H sync from the analogue CVBS is detected, 120 CLK(OSCIN clock) rising edges are counted (10  $\mu$ s for 12 MHz clock or 7.5  $\mu$ s for 16 MHz clock approximately), then the key bytes and DI information are placed onto the bus. DI information is also nibble-ised.

Data is only clocked in and out on rising edge of LLC with LLC2 high.

# Philips Semiconductors - a worldwide company

Argentina: see South America years

Australia: \$4:Waterloo Road, NORTH RYDE, NSAV 2113,

Tel. +61 2 9805 4455, Fax. +61 2 9805 4466

Austria: Computereir. 6, A-1101 WIEN, P.O. Box 213,

Tel. +43 I 60 101, Fax. +43 I 60 101 1210

Belarus: Hotel Minsk Business Center, Bld. 3, r. 1211, Volodorski Str. 6,

220050 MINSK, Tel. +375 172 200 733, Fax. +375 172 200 773

Belgium: see The Netherlands

Brazil: see South America

Bulgaria: Philips Bulgaria Ltd., Energoproject, 15th floor,

51 James Bourchier Blvd., 1407 SOFIA, Tel. +359 2 689 211, Fax. +359 2 689 102

Canada: PHILIPS SEMICONDUCTORS/COMPONENTS.

Tel. +1 800 234 7381

China/Hong Kong: 501 Hong Kong Industrial Technology Centre,

72 Tat Chee Avenue, Kowloon Tong, HONG KONG,

Tei. +852 2319 7888, Fax +852 2319 7700

Colombia: see South America

Czech Republic: See Austria

Denmark: Prags Boulevard 80, PB 1919, DK-2300 COPENHAGEN S.

Tel. +45 32 83 2636, Fax. +45 31 57 1949 Finland: Sinikalliontie 3, FIM-02630 ESPOO.

Tel. +358 9 615800, Fax. +358 9 61580/xxx

France: 4 Rue du Port-aux-Vins, BP317, 92156 SURESNES Cedex,

Tel. +33 1 40 99 6161, Fax. +33 1 40 99 8427

Germany: Hammerbrookstraße 69, D-20037 HAMBURG,

Tel. +49 40 23 53 60, Fax. +49 40 23 536 300

Greece: No. 15, 25th March Street, GFI 17778 TAVROS/ATRENS,

Tel. -30 1 4834 339/239, Fax. +30 1 4814 240

Indie: Philips INDIA Ltd, Shivsagar Estate, A Block, Dr. Annic Besant Rd.

Worli, MUMBAI 400 018, Tel. +91 22 4938 541, Fax. +91 22 4938 722

Indonesia: see Singapore

Ireland: Newstead, Clonskeagh, DUBLIN 14,

Tel. +353 1 7640 000, Fax. +353 1 7640 200

Israci: RAPAC Electronics, 7/Kehilat Saloniki St, TEL AVIV 61180,

Tel +972 3 645 0444, Fax. +972 3 649 1007

Italy: PHILIPS SEMICONDUCTORS, Piezzá IV Novembre 3,

20121 MILANO, Tel. +50 2 6752 2531, Fax. #39 2 6752 2557 Japan: Philips Bldg 13-37, Kohnan 2-chome, Minato-ku, TOKYO 108,

Tel. +81 3 3740 5130, Fax. +81 6 3740 5077

Korea: Philips House, 260-199 Itaewon-dong, Yongsan-ku, SEOUL,

Tel. +82 2 709 1412, Fax. +82 2 709 1415

Malaysia: No. 76 Jalan Universiti, 46200 PETALING JAYA, SELANGOR,

Tel. +60 3 750 5214, Fax. +60 3 757 4880

Mexico: 5900 Gateway East, Suite 200, EL PASO, TEXAS 79905,

Tel. +9-5 800 231 7381

Middle East: see Italy

Netherlands: Postbus 90050, 5600 PB EINDHOVEN, Bldg. VB, Tel. +31 40 27 82785, Fax. +31 40 27 38399

New Zealand: 2 Wagener Flace, C.P.O. Box 1041, AUCKLAND,

Tel. +64 9 849 4160, Fax. +64 9 849 7811

Horway: Box 1, Manglerud 0612, OSLO, Tel +47 22 74 8000, Fax. +47 22 74 8341

Phillippines: Philips Semiconductors Phillippines Inc.,

106 Valero St. Salcedo Village, P.O. Box 2108 MCC, MAKATI,

Metro MANILA, Tel. +63 2 816 6380, Fax. +63 2 817 3474

Poland: Ul. Lukiska 10, PL 04-123 WARSZAWA, Tel. +48 22 612 2831, Fax. +48 22 612 2327

Portugal: sea Spain

Romania: see Italy

Russia: Philips Russia, Ul. Usalcheva 35A, 119048 MOSCOW.

Tel. +7 095 247 9145, Fax. +7 095 247 9144

Singapore: Lorong 1, Toa Payon, SINGAPORE 1231,

Tel. +65 350 2538, Fax. +65 251 6500

Slovakia: see Austria Slovenia: see Italy

South Africa: S.A. FHILIPS Pty Ltd., 195-215 Main Road Martindale,

2092 JOHANNESBURG, P.O. Box 7430 Johannesburg 2000,

Tel. +27 11 470 5911, Fax. +27 11 470 5494

South America: Rua do Recio 220, 5th floor, Suite 51,

04552-903 São Paulo, SÃO PAULO - SP, Brazil.

Tel. +55 11 821 2333, Fax. +55 11 829 1849

Spain: Balmes 22, 08007 BARCELONA, Tel. +34 3 301 6312, Fax. +34 3 301 4107

Sweden: Kottbygatan 7, Akalla, S-16485 STOCKHOLM,

Tel. +46 8 632 2000, Fax. +46 8 632 2745

Switzerland: Allmendstrasse 140, CH-8027 ZÜRICH,

Tel. +41 1 488 2686, Fax. +41 1 481 7730

Taiwan: PHILIPS TAIWAN Ltd., 23-30F, 66,

Chung Hsiao West Road, Sec. 1, P.O. Box 22978,

TAIPEI 100, Tel. +886 2 382 4443. Fax. +886 2 382 4444

Thailand: PHILIPS ELECTRONICS (THAILAND) Ltd.,

209/2 Sanpavulh-Bangna Road Prakanong, BANGKCK 10260,

Tel. +66 2 745 4090, Fax. +66 2 398 0793

Turkey: Talatpasa Cad. No. 5, 80640 GÜLTEPE/ISTANBUL,

Tel. +90 212 279 2770, Fax. +90 212 282 6707

Ukraine: PHILIPS UKRAINE, 4 Patrice Lumumba str., Building B, Floor 7,

252042 KiEY, Tel. +380 44 264 2776, Fax. +380 44 268 0461

United Kingdom: Philips Semiconductors Ltd., 276 Bath Road, Hayes,

MIDDLESEX UB3 5BX, Tel. +44 181 730 5000, Fax. +44 181 754 8421 United States: 811 East Arques Avenue, SUNNYVALE, CA 94088-3409,

Tel. +1 800 234 7381

Uruguay: see South America

Vietnam: see Singapore

Yugoslavia: PHILIPS, Trg N. Pasica 5/v, 11000 BEOGRAD,

Tel. +381 11 625 344, Fax.+381 11 635 777

For all other countries apply to: Philips Semiconductors, Marketing & Sales Communications, Building DE-p, P.O. Box 218, 5600 MD EINDHOVEN, The Notherlands, Fax. +31 40 27 24825

Internet: http://www.scmiconductors.philips.com

© Philips Electronics N.V. 1996

All rights are reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner.

The information presented in this document does not form part of any quotation or contract, is believed to be accurate and reliable and may be changed. without notice. No liability will be accepted by the publisher for any consequence or its use. Publication thereof does not convey nor imply any license

Printed in The Netherlands

Date of release: 01/97

Document order number: 9397 750 01NNN

SCB52

Let's make things better.

**Philips** Semiconductors



PHILIDS